

FIRE SAFETY ITEMS FOR VENDOR TENTS

TENT FABRIC

- Flame resistant to NFPA 701, CPAI-84 or California title 19 if used for cooking and/or tent is enclosed.
- Plastic or plastic tarps should not be used for wind breaks

COMBUSTIBLES

- Area enclosed by the tent and extending out 10 feet must be kept clear of combustible material and vegetation.

FIRE EXTINGUISHERS

- Provided by the Fire Department
- Mounted on the tent pole

SMOKING IS PROHIBITED IN TENT STRUCTURES

PROPANE CYLINDERS

- Positioned at least 5 feet from tent
- Staked and tied off vertical cylinders

CHARCOAL GRILLS

- Positioned 3 feet from tent
- Dispose of hot ashes in a metal can with lid

DEEP-FRYER CLEARANCES

- 3 feet above
- 2 feet on sides
- 2 feet between fryers
- Lids required to control fire

COOK TOPS/GRILL TOPS

- Set on non-combustible surface

GENERATORS

- Positioned at least 5 feet from tent
- Protected from contact by fencing or enclosure
- No refueling may take place during normal operating hours

SIGNAGE

- Enclosed tents must have exit signs